

## Montageanleitung Austausch Distanzstücke

### Wichtiger Hinweis!

Bei der Verwendung der Antipanik-Druckstange **907300 – 907304** in Kombination mit dem Antipanik-Gegenkasten **977400 / 917400**, muss der Drehwinkel bei der Antipanik-Druckstange von 45° auf 40° begrenzt werden!

Dazu werden die Distanzstücke ausgetauscht, welche im Befestigungssatz **907366** enthalten sind.

## Instructions de montage Remplacement des entretoises

### Remarque importante!

Lors de l'utilisation de la pushbar anti-panique **907300 – 907304** en combinaison avec la contre-bascule anti-panique **977400 / 917400**, l'angle d'ouverture de la pushbar anti-panique doit être limité de 45° à 40°!

Cela nécessite le remplacement des entretoises, lesquelles sont contenues dans le kit de fixation **907366**.

## Assembly instructions Replacement of spacers

### Important note!

Using the anti-panic touch-bar **907300 – 907304** in combination with the opposite lock anti-panic **977400 / 917400**, the angle of tilt must be limited in the touch-bar from 45° to 40°!

This is done by replacing the spacers, which are contained in the fastening set **907366**.

